

cannondale

Manual Reset

NOTICE:

Do not open the upper collar for the manual reset procedure.

Perform every 50 hours.

1. With your bike on the floor.
2. Cover the brake rotor with a clean shop towel. Remove the Schrader valve cap and hold the valve to release all air pressure. It is normal for a small amount of oil to be expelled with the escaping air.


WARNING

Contamination can result in reduced or lost braking performance.

3. Hold the valve open while fully compressing the LEFTY with the handlebar until it bottoms out. With the air out, using moderate force, bottom out the LEFTY firmly several times.
4. Now, measure from the bottom of the spindle to the top of the outer collar. Repeat step three until the correct measurement for your LEFTY is reached.

LEFTY	LENGTH (A)
29"	578 +/- 3mm
26"	548 +/- 3mm

5. When you are finished, reset sag. See page 6.



File Name: cannondale lefty xlr manual.pdf

Size: 2137 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 26 May 2019, 16:16 PM

Rating: 4.6/5 from 579 votes.

Status: AVAILABLE

Last checked: 5 Minutes ago!

In order to read or download cannondale lefty xlr manual ebook, you need to create a FREE account.

[Download Now!](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with cannondale lefty xlr manual . To get started finding cannondale lefty xlr manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

cannondale lefty xlr manual

Please review our cookie policy to learn more or to change your cookie settings. By continuing to browse, you agree to our use of cookies. Operating since 2004, with a focus on retail suspension sales and service since 2014, Cyclinic is the goto for suspension sales and service in Australia and New Zealand. Keep both for future reference. Keep both for future reference. Indicates special precautions that must be taken to NOTICE avoid damage. A TIP provides helpful information. This manual meets EN standards 14764, 14766, and 14781. Please read your Cannondale Bicycle Owner's Manual for more information about Intended Use. Note brake alignment shims between brake bosses and the caliper. Replace correctly during reinstallation. 2. PLEASE ASK YOUR CANNONDALE DEALER FOR HELP 4. Once the hub has been drawn onto the hub completely, WHEN INSTALLING COMPATIBLE FRONT BRAKE SYSTEMS. This is not an adjustment when used with Lefty. This dial has been set at the factory. OPEN POSITION LOCKED POSITION Press blue button to engage lockout. PBR Rebound Dial ROTATE DIAL IN THE "" DIRECTION COUNTERCLOCKWISE TO INCREASE REBOUND SPEED FASTER. Remove the Schrader valve cap. Attach a bicycle suspension pump to the valve end. 2. Pressurize the fork to an initial starting air pressure of 6575% of rider weight. 3. Before installation, make sure all part surfaces are clean. Apply a highquality bicycle bearing grease to the surfaces indicated. See shaded areas in illustration, next page. Make sure both upper and lower head tube bearings are fully seated in the headtube. Follow these steps carefully 1. Here are some important points to remember about the kits See the detail in the illustration. Ask your Cannondale KIT, FRAME BUMPER, LEFTY Dealer for help. Always tighten securely, but do not overtighten the clamps. Replacement cable clamps are available through a Cannondale Dealer. IMPORTANT If you find boot damage, the area under the fork should also be inspected for damage. http://gleb777.com/fck_upload/dmr-e75v-manual.xml

- **cannondale lefty xlr manual, cannondale lefty 29er carbon xlr manual, cannondale lefty xlr manual, cannondale lefty xlr manual pdf, cannondale lefty xlr manual download, cannondale lefty xlr manual instructions, cannondale lefty xlr manual 2017.**

The cleaning procedure is the same for carbon or alloy outer tube forks. We provide the information in the supplement, however, we recommend that you always have this procedure performed by your Cannondale Dealer. It is available on the Policies page of our website at Be sure to read the exclusions listed in the limited warranty. For example, damage from accidents and improper maintenance are not covered. Cycling Sports Group Europe, B.V. Cycling Sports Group 172 Friendship Road, mail Postbus 5100 Vantage Way, The Fulcrum, Bedford, Pennsylvania, 155226600, USA visits Hanzepoort 27 Poole, Dorset, BH12 4NU Voice 1800BIKEUSA. Indicates special precautions that must be NOTICE taken to avoid damage. This manual meets EN standards 14764, 14766, and 14781. OR KILLED IN AN ACCIDENT IF YOU IGNORE If your LEFTY is damaged, do not ride it. Brake Housing Guide 11. Bonded Lower Clamp 12. Set it according to the LEFTY travel. Sag is set by changing the air pressure through the Schrader valve at the bottom of the LEFTY. Set Recommended Initial Air Pressure Set before measuring sag 26ER. Attach a bicycle suspension pump to the Schrader valve 2. See Figure 1. 2. Set the recommended initial starting air pressure according to your weight. Push black button in and shown. In the locked position, LEFTY travel is The red rebound dial 1 is in the down locked. The red rebound dial is up. To go position. This step draws the stem by a professional bike mechanic. Note brake alignment shims between brake bosses and the caliper. Disassembly and inspection by a suspension professional is required to evaluate the

internal and external parts, identify wear or damage. Clean water and common liquid dish washing soap will work best. Be sure to cover the adjusters with a clean plastic bag secured with a rubber band or masking tape. Spray off heavy dirt before wiping. Tall clamp width bumper Moto Guard The LEFTY hybrid moto guard protects the inner tube surface from damage. It also supports the brake line. <http://www.drjhsderma.com/pics/dmr-e75v-manual.xml>

Remove the Schrader valve cap and hold the valve to release all air pressure. It is available on the Policies page of our website at Be sure to read the exclusions listed in the limited warranty. For example, damage from accidents and improper maintenance are not covered. Cycling Sports Group Europe, B.V. Cycling Sports Group 172 Friendship Road. My challenge is to demount a Hybrid Lefty XLR. Its all done but the last step confuse me. I cant pull away the lower tube from the upper. Is there any secret lock. Cannot be done by end users, or even well trained shop mechanics. I work on thousands of Leftys, Im not even allowed in currently, though that is supposed to change early this Spring, and I have to say about damn time.. In the US The Cannondale Factory Tech Room is the only place it can be done at this point. In the EU, I believe there are 3 or 4 Cannondale service centers that have been given the go ahead to start doing this.. Thanks for your reply, if I understand correctly, there is no possibility to change needle bearing myself. Mine is a 2014 Lefty XLR 100mm. Also, I saw on youtube someone saying you dont have to take it apart to do this. Just let the air out and use force bottoming out the fork. Kind of scared to do this in fear of breaking something. Thanks! It still requires manual resets periodically, but running the fork soft enough that you bottom out now and then every ride or three, youll sort of keep it in check, so to speak. To get fully back, a manual reset is the answer. I dont let the air out when doing a manual one, but if youre an anal retentive, safety first and foremost no matter how much extra time it takes, then sure, do that first. The concern is if your damper has fully backed out of the lower leg, then it will fly out at you when you take the collar off, but frankly, after working on literally thousands, Ive had 2 or 3 ever, with this issue, and all were older forks basically ridden till the wheels fell off without ever seeing service.

Older ones with boots, the reset was accomplished by forcibly extending the fork instead of compressing. Yes, you must do it on all Leftys. Takes almost no time at all, but some would have you feel that its a huge hassle, not sure why, they never gripe about putting air in tires or lube in the chain. It still requires manual resets periodically, but running the fork soft enough that you bottom out now and then every ride or three, youll sort of keep it in check, so to speak. To get fully back, a manual reset is the answer. I seem to be at 85mm travel, so Im reading it is probably time for a bearing reset. Im just now learning about all this. Never done it before. I removed all the air from the lower port. Then I removed the top cap with a 35mm socket, but I couldnt see how to remove the split rings to disconnect the damper shaft from the top cap. It looks different than any of the tutorials I have read. So I left that alone and I pushed the handlebars down and bottomed the travel completely in that direction. Then I tried, to extend the fork to top out the linear bearings. But in this direction the top cap was in the way. What part am I doing wrong. I dont think I gained any extra travel with this experiment. Thanks. ConsumerREVIEW.com, a business unit of Invenda. Vlo certi conforme aux exigences du dcret N 95937 du 24 aot 1995 norme NFR030 In this supplement, particularly important information is presented in the following ways WARNING Indicates a hazardous situation which, if not avoided, could result in death or serious injury. NOTICE Indicates special precautions that must be taken to avoid damage. For the latest product information, go to SAFETY INFORMATION About This Supplement Cannondale Owners Manual Supplements provide important model specific safety, maintenance, and technical information. They are not replacements for your Cannondale Bicycle Owners Manual. This supplement may be one of several for your bike. Be sure to obtain and read all of them.

If you need a manual or supplement, or have a question about your bike, please contact your Cannondale Dealer immediately, or call us at one of the telephone numbers listed on the back cover

of this manual. You can download Adobe Acrobat PDF versions of any Cannondale Owners Manuals or Supplements from our website. This manual is not a comprehensive safety or service manual for your bike. This manual does not include assembly instructions for your bike. All Cannondale bikes must be completely assembled and inspected for proper operation by a Cannondale Dealer before delivery to the owner. **WARNING** This supplement may include procedures beyond the scope of general mechanical aptitude. Special tools, skills, and knowledge may be required. Improper mechanical work increases the risk of an accident. Any bicycle accident has risk of serious injury, paralysis or death. To minimize risk we strongly recommend that owners always have mechanical work done by an authorized Cannondale retailer. **INTENDED FORK USE LEFTY SPEED 100 mm, LEFTY 29er 100mm, 90mm Lefty MAX 140 mm, Lefty Ultra 120 mm CrossCountry, Marathon, Hardtails All Mountain, Overmountain ASTM CONDITION 3 ASTM F2043 For rough offroad riding and jumps less than 24 61 cm ASTM CONDITION 4 ASTM F2043 For extreme offroad riding FORK INTENDED For crosscountry riding and racing which ranges from mild to aggressive over intermediate terrain e.g., hilly with small obstacles like roots, rocks, loose surfaces and hard pack and depressions. There are no large sick drop or drop offs, jumps or launches wooden structures, dirt embankments requiring long suspension travel or heavy duty components. Crosscountry and marathon equipment tires, shocks, frames, drive trains are light weight, favoring nimble speed over brute force. Suspension travel is relatively short since the bike is intended to move quickly on the ground and not spend time in the air landing hard and hammering through things. FORK INTENDED For trail and uphill riding.**

All Mountain bicycles are 1 more heavy duty than cross country bikes or trail bikes, but less heavy duty than Freeride bikes, 2 lighter and more nimble than Freeride bikes, 3 heavier and have more suspension travel than a cross country bike, allowing them to be ridden in more difficult terrain, over larger obstacles and moderate jumps, 4 intermediate in suspension travel and use components that fit the intermediate intended use, 5 cover a fairly wide range of intended use, and within this range are models that are more or less heavy duty. Talk to your retailer about your needs and these models. Please read your Cannondale Bicycle Owners Manual for more information about Intended Use and Conditions 15. 126564.PDF **FORK DAMAGE WARNING STOP RIDING A DAMAGED FORK IMMEDIATELY.** The following conditions indicate that serious fork damage is present 1. Any unusual klunking or knocking noises. 2. A change in fork travel. 3. An overextended, elongated, or compressed boot. 4. Changes from the way the fork had been working 5. Loss of adjustment features, oil leaks, or air leaks. 6. Crash or impact damage deep scratches, gouges, dents, or bending 7. Small cracks under the bolt head of upper and lower clamp bolts. This inspection requires the removal of the bolts. Horizontal cracks above and below the intersection of the upper and lower clamps with the outer tube portion of the Lefty carbon structure. Vertical cracks in the outer tube where the races and needle bearings run. These may show as long, straight lines perhaps several lines parallel to each other. Also, please read Inspect For Safety in PART II, Section D. of your Cannondale Bicycle Owners Manual. If your fork requires service, please take it to an Authorized Cannondale Dealer. **DO NOT** 1. Drill, file, cut or remove material from any fork part. 2. Weld, clamp, or bond anything to the fork. 3. Attempt to remove or add the damping cartridge or other internal fork parts.

Your dealer can arrange for the necessary service through our Factory Tech Room. All air pressure must be released before servicing any fork. Never attempt to work on a pressurized fork. **YOU CAN BE SEVERELY INJURED, PARALYZED, OR KILLED IN AN ACCIDENT IF YOU IGNORE THIS WARNING.** 29ER TIRE CLEARANCE CHECK Please see the information starting on page 30.

Cannondale needed Pancho and Lefty Lefty Ocho 2019 E K31039 Lefty Stoplock Adapter Hourglass Bolt F K31019 Lefty Stoplock Brake Adapter Catalogo cannondale Cannondale 2015 Waiting for lefty 2007 Lefty Speed Dlr2 Sl Owners Manual Supplement En LEFTY HYBRID. Cannondale Lefty Ocho Ocho. Besprechen Sie die Art und Weise, in der Sie Ihr Bike bzw. Achten Sie auf die Beilagscheiben

zur Justierung zwischen Bremssockeln und Sattel. Hier ist in Verbindung mit Lefty nichts einstellbar. Die Einstellung ist bereits im Werk erfolgt. Entfernen Sie die Kappe des Schrader Ventils. Kontrollieren Sie, dass die oberen und unteren Lager des Headtubes richtig eingesetzt sind. Dieses Adaptersystem muss von einem qualifizierten Fahrradmechaniker installiert werden. Ziehen Sie die Klammern gut, aber nicht zu fest, an. Reinigen und Fetten 1. Lassen Sie den gesamten Luftdruck durch das Schrader Ventil unten an der Gabel ab. 2. Einheiten oder anderer Teile der Gabel liegen. Keep both for future reference. CANNONDALE USA CANNONDALE EUROPE CANNONDALE UK Cycling Sports Group, Inc. Cycling Sports Group Europe, B.V. Cycling Sports Group 172 Friendship Road, . Registrieren Sie sich jetzt. TIP A TIP provides helpful information. They are not replacements for your Cannondale Bicycle Owner's Manual. This manual is not a comprehensive safety or service manual for your bike. To minimize risk we strongly recommend that owners always have mechanical work done by an authorized Cannondale retailer. Please read your Cannondale Bicycle Owner's Manual for more information about Intended Use and Conditions 15.

YOU CAN BE SEVERELY INJURED, PARALYZED OR KILLED IN AN ACCIDENT IF YOU IGNORE THIS WARNING. Change in travel. Changes in normal functions. Loss of adjustments features, oil leaks, or air leaks. Crash or impact damage deep scratches, gouges, dents, or bending Any small cracks under the bolt head of upper and lower clamp bolts. Horizontal cracks above and below the intersection of the upper and lower clamps with the outer tube portion of the Lefty structure. Please read Inspect For Safety in PART II, Section D. of your Cannondale Bicycle Owner's Manual. If your LEFTY is damaged, do not ride it. Contact your Cannondale Dealer to arrange service through an authorized service center. Improper service or modification can lead to serious fork damage or serious personal injury. Do not disassemble the fork. Do not attempt modification in any way. Do not drill, file, cut or remove material from any part. Do not attempt to repair damage. Do not weld, clamp, or bond anything to the fork. Do not attempt to remove the damping cartridge or other internal fork parts. The MAINTENANCE section of this supplement includes information about regular owner maintenance practices that can keep your fork in good operating condition. All other service and maintenance procedures must be completed through an Authorized Headshok Service Center. Contact your Authorized Cannondale Dealer for more information. **YOU CAN BE SEVERELY INJURED, PARALYZED OR KILLED IN AN ACCIDENT IF YOU IGNORE THIS WARNING.** 29R Travel Reduction WARNING DO NOT REMOVE 29 ER TRAVEL REDUCERS. LEFTY for 29 wheel bikes have internal travel reducers to maintain correct clearance with the wheel and frame. If reducers are removed or installed incorrectly, and the air spring pressure is lost or too low, and the fork is loaded in a large compression event, a rotating tire could come into contact with the frame causing the wheel to stop suddenly. This can throw a rider off the bicycle or result in a loss of control and crash.

Measure between the top of the properly inflated tire and the bottom of the fork steerer. Bonded Lower Clamp 12. Guard 13. Guard Brake Housing Clamp 14. Lower Collar Assy. 15. Sag ORing 16. OPI Inner Tube 17. Guard Mounting Screws 18. Hub Spindle 19. Inner Bearing Land 20. Outer Bearing Land 21. Axle Bolt Threads 22. Schrader Valve. Integrated Lower Clamp 11. Guard 12. Guard Brake Housing Clamp 13. Lower Collar Assy. 14. Sag ORing 15. OPI Inner Tube 16. Guard Mounting Screws 17. Hub Spindle 18. Inner Bearing Land 19. Outer Bearing Land 20. Axle Bolt Threads 21. Schrader Valve Set it according to the LEFTY travel. Set Recommended Initial Air Pressure Set before measuring sag 26ER RIDER WT. 29ER PSI Bar Kg PSI Bar 81 5,,6 88 6,,2 94 6,,,,,,,,,,,,,6 Be aware that conventional pump gages have variations. Therefore, we recommend you to fine tune your set up with the Recommended Sag. Attach a bicycle suspension pump to the Schrader valve 2. See Figure Set the recommended initial starting air pressure according to your weight. 3. Slide the sag Oring 3 against the wiper seal 4. See Figure Sit on bike in riding position and dismount. Note Your riding position affects weight distribution and therefore sag. For example, in the Attack position Figure 3. Make sure pump and valve are clean before attachment. SAG 4 7 The XLR lever button 1 is retracted as shown. To go to the locked position, push the black button in and

release it. **LOCKED POSITION** In the locked position, **LEFTY** travel is locked. The **XLR** lever button is extended as shown. Push black button in and release it to return to the open position. **XLR Rebound Dial** Rotate the red rebound dial in the direction counterclockwise to increase rebound speed faster. The red rebound dial 1 is in the down position. To go to the locked position, press the blue button 2. To go back to the open position, press the red rebound dial down until it clicks.

PBR Rebound Dial Rotate dial in the direction counterclockwise to increase rebound speed faster. Before installation, make sure all part surfaces are clean. Follow these steps carefully 1. Install the upper bearing seal onto the upper headtube bearing. The open side of the seal faces the bearing. 2. Position the **Lefty** onto the headtube by sliding the **Lefty** clamps over the head tube and seal. 3. Slide the nylon washer onto the **OPI** stem with rounded side facing the shoulder of the stem. 4. Apply grease to fully cover stem bearing surface and the internal steerer threads. Also apply grease to the inner race of the upper and lower headtube bearings. Slide the desired number of spacers onto the stem. You may use 03 spacers onto the **OPI** stem. Use only **OPI** spacers. With a soft mallet, carefully drive stem straight down until fully seated. 6. Next, install the nylon washer onto steerer with the rounded side of the washer facing the steerer bottom flange. Grease entire steerer lower bearing surface and the steerer threads. This step draws the stem and spacer stack to the upper clamp. When tightened, align the stem and only hand tighten the upper clamp bolt. 9. Retighten the steerer to 12 Nm, ensuring the stem and **Lefty** do not move relative to each other. Then, hand tighten the lower clamp bolt. 10. Finish by tightening both the upper and lower **Lefty** clamp bolts to the final torque of 79 Nm. 11. Apply **Loctite 242** and tighten the handlebar clamp bolts evenly and equally in a cross pattern to 6 Nm. Do not exceed 9 Nm. Overtightening can damage the **OPI** steerer parts. 7. Insert steerer into bearing and carefully hand thread into stem. Do not use a tool. Continue hand threading until the steerer 10 Note brake alignment shims between brake bosses and the caliper. Replace correctly during reinstallation See Figure 2. Insert a 5 mm Allen key into the axle hub bolt and turn the the hub extraction bolt counterclockwise.

Continue turning the extraction bolt until the wheel can be removed easily from the spindle end. See Figure 3. 2 **NOTICE** Make sure the axle bolt is completely disengaged before attempting to remove the wheel. Never try to pull the wheel off forcefully. When the wheel is off, to keep dirt out, cover the hub opening. Protect spindle from damage when wheel is removed. 3 13 Take corrective action if necessary. Wipe the spindle clean with a dry shop towel. Apply a highquality bike grease to I.D. of the bearings inside the hub. 2. Slide the wheel straight onto the spindle. 3. Turn the axle bolt clockwise to engage the spindle threads. Make sure the wheel and spindle are supported while tightening the hub bolt. 4. Once the hub has been drawn onto the hub completely, use torque wrench to tighten to final 15.0 N m 133.0 In Lbs. 5. Reinstall the brake caliper. Tighten bolts to 78.0 In Lbf 9.0 N m. 6. Spin the wheel to make sure it moves freely. Be sure to test the brakes for proper operation before riding. When mounting **IS** compatible brake systems Follow brake manufacturer s instructions when mounting the brake caliper to the spindle brake bosses. Do not modify the fork in any way. **USE ONLY THE LEFTY 16mm CALIPER BOLTS TO MOUNT THE BRAKE.** Longer bolts can result in contact with the brake rotor causing severe damage. Check clearance between the bolt tips and rotor after remounting the caliper. You must establish a schedule appropriate to your riding style and conditions. Damaged parts must be replaced with new ones and the work must also include any work described in any technical bulletins or product recalls. Clean water and common liquid dish washing soap will work best. Spray off heavy dirt before wiping. Spray indirectly. **NOTICE DO NOT USE A PRESSURE WASHER.** Use a low pressure garden hose. Power washing will force contaminants into the fork promoting corrosion, immediately damaging, or result in accelerated wear.

We urge you to have your Dealer correctly torque all fasteners using a torque wrench. If you decide to tighten fasteners yourself always use a good torque wrench. The bumper cushions the frame from

contact with the LEFTY. Replace it with a new one if it ever becomes damaged, torn, or missing. **REPLACEMENT** Before replacement, gently clean the LEFTY outer tube with warm soapy water and wipe dry. Remove the backing from the new bumper, position and affix by pressing firmly against the outer tube. **IMPORTANT** Be sure to position the bumper so that when the handlebar is rotated to the left, the bumper prevents fork contact with the the frame. Frame damage can result from using the wrong bumper or positioning a bumper incorrectly. It also supports the brake line. Check it periodically. Make sure it is in good condition and attached properly. **NOTICE** Replace guard with a new one if it becomes damaged. Remove the Schrader valve cap and hold the valve to release all air pressure. It is normal for a small amount of oil to be expelled with the escaping air. **A WARNING** Contamination can result in reduced or lost braking performance. 3. Hold the valve open while fully compressing the LEFTY with the the handlebar until it bottoms out. With the air out, using moderate force, bottom out the LEFTY firmly several times. 4. Now, measure from the bottom of the spindle to the top of the outer collar. Repeat step three until the correct measurement for your LEFTY is reached. It is available on the Policies page of our website at Be sure to read the exclusions listed in the limited warranty. For example, damage from accidents and improper maintenance are not covered. Definitions related to forks The fork structure is covered in the FRAMES section of the Cannondale Limited Warranty. Fork structure means certain structural parts of the fork, specifically the fork legs, outer tube, the steerer tube, steerer tube clamps and the inner tubes with attached dropouts or spindle.

Cable clamps, needle bearings, races, and bushings which are part of the telescopic assembly are normal wear and tear items and ARE NOT covered by the limited lifetime warranty. The internal fork internal parts are covered by the 1 year 2 years in EU countries warranty against defects in materials or workmanship described in the COMPONENTS section of the Cannondale Limited Warranty. Internal fork parts are defined as items such as damping cartridges and their internal parts, seals, orings, air cylinders, air pistons, springs, elastomers, bumpers, bushings, needle bearings, races, and oil. Normal wear and tear on these items is NOT covered by this 1 year 2 in EU warranty. Like brake pads on a car, you should expect to have these items professionally replaced or renewed as you use the fork and they wear. FR Nous voulons ici vous offrir la possibilite de suivre l entretien de votre fourche afin de garder son fonctionn ement optimal. It is a document to be used in conjunction This supplement provides additional and important model specific safety, Developed to perform at a high level, it is important that you follow the operation and maintenance instructions Keep it for future reference. LEFTY SPEED FOX RLC 110mm Owner s Manual Supplement 120867.PDF CONTENTS safety information. About This Patents World Wide Vehicles without drive axle must not be moved, You have invested in a suspension system that offers light weight, maximum adjustability, and absolute steering precision. Developed in partnership with Ohlins Racing, the Double Barrel brings revolutionary Failure to follow the safety rules and other After replacing brake pads and before moving vehicle, depress brake pedal several times firmly to properly DO NOT DESTROY It is the customer s responsibility to have all operators and service personnel read and understand this manual.

We know that you must be raring to go but before you do there s a few little things still to do to get you up Failure to do so can result in serious injury. Preassembly of parts Clean the bolts and the threads in the hat with acetone. Welcome to the world of the ELLIPTICAL CROSS TRAINER. The ELLIPTICAL CROSS TRAINER is one of the finest and most comprehensive pieces of Table of Contents GB Assembly Guide Read instructions before assembling this How the Cab Leveling and Chassis Leveling Valves Work Failure to follow the safety rules and other basic safety precautions may result in serious Put the tie rod end in the steering arm and snug the castle nut before adjusting. It is an essential part of the product, and you should keep it in a safe place for future reference. **MECHANIC** Repair Information. W Series Geroler Motors Technical description The legs are made from 6061 aluminium, mounted with CNC machined fittings, the stanchions are from

WARNING! Always have the vehicle under inspection on level ground, in park with the emergency brake on. Always wear protective eyewear, gloves and necessary Crated Unit Assembly Manual Important Safety Instructions Assembly Instructions Parts and Hardware Identification The pallet jacks you are servicing Performance Mfg. strives to provide you with the very best chassis and components on the market today. Your satisfaction We appreciate the market is slightly clouded with various brands of so called mini bmx. We appreciate the market is slightly clouded with various brands of so called mini bmx. However, Rocker is very different from other brands; it was Read all instructions carefully before commencing any work. Always wear safety equipment. Some installation steps will require two or more installers. Wheel is supported You can find these numbers printed on the bottom of the table.TITAN Fuel Tanks TITAN Fuel Tanks INSTALLATION INSTRUCTIONS G e n e r a t i o n V Extended Fork Height.

Visit our website at [Users who are not professionally trained for bicycle](#) To use this website, you must agree to our Privacy Policy, including cookie policy.